


# Maytag MAF25MC4VL 06 - DOOR LOCK (MAF25MC4Vx)



Maytag Residential Maytag MAF25MC4VL Washer Parts Parts Diagram 06 - DOOR LOCK (MAF25MC4Vx)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">24001640</a>			Door Lock Complete
"	<a href="#">24001642</a>			Screw, S.s.
002	24001483		Not Available	CATCH, DOOR LOCK
003	<a href="#">24001323</a>			Screw
004	24001484		Not Available	COVER, DOOR LOCK PLATE
005	<a href="#">24001295</a>			Lockwasher, S.s.
006	24001342	<a href="#">74005230</a>		Nut, Lock
007	<a href="#">24001485</a>			Washer, Shoulder
008	<a href="#">24001101</a>			Solenoid, Door Rel
009	<a href="#">24001358</a>			Washer, Flat
010	<a href="#">24001250</a>			Button, Push
011	24001481	<a href="#">Y707702</a>		Locknut
012	<a href="#">24001480</a>			Washer, Teflon
013	24001487		Not Available	COVER, DOOR LOCK ASSY.
014	<a href="#">24001476</a>			Nut, Fiberlock
015	<a href="#">24001229</a>			Switch, Door Lock

016	24001477		Not Available	SPACER, NYLON (No.6)
017	<a href="#">24001479</a>			Screw, S.s.
018	<a href="#">24001643</a>			Screw, S.s.
019	24001301	<a href="#">67006964</a>		Screw, Glide
020	NLA		Not Available	PLATE, DOOR LOCK
021	<a href="#">24001102</a>			Solenoid, Door Lck
022	<a href="#">24001305</a>			Nut, Fiberlock
023	<a href="#">24001255</a>			Switch, Door Handle
"	24001257	<a href="#">24001255</a>		Switch, Door Handle
024	<a href="#">24001425</a>			Nut, Fiberlock, Pltd
025	<a href="#">24001230</a>			Lever, Door Lock
026	<a href="#">24001293</a>			Spring, Torsion
027	<a href="#">24001559</a>			Shim, Door Lock
028	24001488		Not Available	SHIELD, SPLASH (DOOR LOCK)

