


# Maytag MAF25MC4VW 01 - CONTROL MODULE (MAF25MC4Vx)



Maytag Residential Maytag MAF25MC4VW Washer Parts Parts Diagram 01 - CONTROL MODULE (MAF25MC4Vx)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	24001105	<a href="#">24002051</a>		Contacto-
002	24001104		Not Available	CONTACTOR, AUX. ADDER
003	NLA		Not Available	SWITCH, TRI LEVEL---N
004	<a href="#">24001233</a>			Protector, Overload
005	W10124350		Not Available	PART NUMBER NOT AVAILABLE
006	24001412		Not Available	STRIP, TERMINAL
007	24001414	<a href="#">4450038</a>		Screw
008	NLA		Not Available	DECAL,INSUL. TERM STRIP (1-8)
009	NLA		Not Available	DECAL,INSUL. TERM STRIP (9-16)
010	NLA		Not Available	DECAL,INSUL. TERM STRIP (17-24)
011	NLA		Not Available	DECAL,INSUL. TERM STRIP (25-32)
012	24001030		Not Available	DECAL,INSUL. TERM STIRP (33-40)
013	<a href="#">24001415</a>			Washer, S.s.

014	24001417	<a href="#">7103P070-60</a>		Nut, Top Pilot
015	W10124350		Not Available	PART NUMBER NOT AVAILABLE
016	24001209		Not Available	LIGHT, NEON (1/3W, 125VAC)
017	24001342	<a href="#">74005230</a>		Nut, Lock
018	<a href="#">24001576</a>			Washer, Flat
019	<a href="#">24001214</a>			Bracket, Ind. Light
"	24001841	<a href="#">24001214</a>		Bracket, Ind. Light
020	24001210	<a href="#">215564</a>		Lens, Indicator Light
021	24001204		Not Available	KNOB
022	<a href="#">24001207</a>			Switch, Cycle Select
023	<a href="#">24001357</a>			Screw, Stainless Steel
024	<a href="#">24001358</a>			Washer, Flat
025	24001411	<a href="#">313806</a>		Screw
026	<a href="#">24001577</a>			Motor, Timer
027	<a href="#">24001178</a>			Kit, Timer Cycle
028	W10124350		Not Available	PART NUMBER NOT AVAILABLE
029	24001578	<a href="#">3196170</a>		Screw
030	<a href="#">24001247</a>			Capacitor, Door Lock
031	24001248		Not Available	PC BOARD, DOOR UNLOCK (110V)
032	<a href="#">24001579</a>			Washer, S.s.
033	<a href="#">24001580</a>			Screw, S.s.
034	24001419	<a href="#">W10139757</a>		Nut
035	<a href="#">24001295</a>			Lockwasher, S.s.
036	<a href="#">24001176</a>			Kit, Timer Delay
037	<a href="#">24001235</a>			Kit, Switch
038	<a href="#">24001425</a>			Nut, Fiberlock, Pltd
039	<a href="#">24001576</a>			Washer, Flat
040	24001593	<a href="#">132780</a>		Screw
041	24001594		Not Available	BRACKET, SINPAC SWITCH
042	24001744		Not Available	BOOT, PUSH BUTTON
043	<a href="#">24001254</a>			Switch, Momentary
044	<a href="#">24001245</a>			Fuse, Slo Blo

