


**Maytag MAF25MC4VW 05 - DOOR & RELATED ASSEMBLY  
(MAF25MC4Vx)**



Maytag Residential Maytag MAF25MC4VW Washer Parts Parts Diagram 05 - DOOR & RELATED ASSEMBLY (MAF25MC4Vx)

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	24001407		Not Available	DECAL, RED DOT
002	<a href="#">24001103</a>			Rod, Push Button
003	<a href="#">24001721</a>			Pin, Spring
004	<a href="#">24001338</a>			Spring, Door Lock
005	<a href="#">24001336</a>			Handle, Door
006	<a href="#">24001339</a>			Washer, Nylon
007	24001341	<a href="#">3400814</a>		Screw
008	24001462		Not Available	DECAL, PUSH BUTTON RED
009	24001636	<a href="#">24001638</a>		Door Assembly
"	<a href="#">24001638</a>			Door Assembly
010	24001340		Not Available	SPACER, DOOR HANDLE
011	24001342	<a href="#">74005230</a>		Nut, Lock
012	<a href="#">24001075</a>			Gasket, Door
013	<a href="#">24001343</a>			Arm, Latch
014	24001465		Not Available	DECAL, ROTATION SPIN

014	24001400	Not Available	(CCW)
015	24001098	Not Available	GLASS, DOOR
016	W10124350	Not Available	PART NUMBER NOT AVAILABLE
017	<a href="#">24001466</a>		Shim, Hinge
018	<a href="#">24001333</a>		Hinge, Door
019	<a href="#">24001305</a>		Nut, Fiberlock
020	<a href="#">24001334</a>		Mount, Door
021	<a href="#">24001467</a>		Screw, S.s.
022	24001417	<a href="#">7103P070-60</a>	Nut, Top Pilot
023	<a href="#">24001415</a>		Washer, S.s.
024	24001470	Not Available	MAGNET
025	24001414	<a href="#">4450038</a>	Screw
026	<a href="#">24001472</a>		Switch, Magnet Position
027	<a href="#">24001185</a>		Gasket Kit
028	24001135	Not Available	(INCLUDES TRIM & SCREWS)
"	24001136	Not Available	PANEL KIT, FRONT COIN (ALM) (INCLUDES TRIM & SCREWS)
"	24001137	Not Available	PANEL KIT, FRONT COIN (STNLSS) (INCLUDES TRIM & SCREWS)
"	NLA	Not Available	PANEL KIT, FRONT COIN (WHT)
029	24001474	<a href="#">3400086</a>	Screw, 10-32 X 3/8
030	24001475	Not Available	RIVET, POP S.S. (1/8 X 1/4)

