


Maytag MAH14PDBAW 11 - DOOR LATCH ASSY



Maytag Residential Maytag MAH14PDBAW Washer Parts Parts Diagram 11 - DOOR LATCH ASSY
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|------------------------|--------|-------------------------------|
| 001 | 22003716 | | | Rotating Gear, Latch |
| 002 | 22003717 | | | Spring, Latch |
| 003 | 22001352 | | | Screw, Check Switch |
| 004 | 22002165 | | | Washer, Door Lock Switch |
| 005 | 22002162 | | | Switch, Door Lock Spin Enable |
| 006 | 22002158 | | | Spring, Gear Return |
| 007 | 22003722 | | | Switch Holder Assembly, Latch |
| 008 | 22003719 | | | Screw, Latch |
| 009 | 22003720 | | | Nut, Latch |
| 010 | 22002957 | | | Cover, Latch Assembly |
| 011 | 22002435 | 241877 | | Screw |
| 012 | 22003055 | | | Ramp, Door Hoop |
| 013 | 22002164 | | | Cable, Door |
| 014 | 22003715 | | | Sliding Gear, Latch |
| 015 | 22003721 | | | Spring, Axle / Latch |
| 016 | 22003718 | | | Axle, Latch |

