


Maytag MAH20PDA3W 02 - CONTROL CENTER (PD)



Maytag Residential Maytag MAH20PDA3W Washer Parts Parts Diagram 02 - CONTROL CENTER (PD)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22002480			Vault, Coin PD Coin Drop Supplied By Dist.
002	22001810		Not Available	STRAP, MOUNTING
003	22001996	3370225		Screw
004	910309			Washer, Mounting Strap
005	22002072			Gasket, Control Center
006	Y052740	62739		Nut, Lock
007	213035			Bolt, Locking
008	910181			Lockwasher, Terminal Block
009	NLA		Not Available	CAM, LOCKING
010	33001250			Switch, Vault And Service Door
"	912012	3400409		Screw
011	22003041			Coin Drop Assembly
012	216200			Face Plate Return Button
013	22001910	22003679		Timer Access Door Assembly
014	22001965			Optic Switch Assembly

015	314665		Screw, Switch Assembly
016	216068		Screw, Coin Drop
017	22001404		Bracket, Service Switch
018	22001069		Screw, Vault To Control Cover
019	22001966		Harness, Sensor Switch
020	206637		Lock Kit
"	215033	W10140858	Key
021	W10124350	Not Available	NOT PROVIDED BY MAYTAG

