


Maytag MAH20PDA3W 03 - TOP



Maytag [Residential Maytag MAH20PDA3W Washer Parts](#) Parts Diagram 03 - TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22003586	22004178		Cover, Top
"	NLA		Not Available	COVER, TOP (WHT)
002	205161	489503		Clamp
003	22002909			Lid, Dispenser
004	22002940	22003665		Bezel, Dispenser
005	Y912678	6-912678		Pin- Hinge
006	Y912679			Pin, Hinge
007	22002060	400021-1		Screw
008	205161	489503		Clamp
009	22002556			Screw, Baffle
"	33002193			Hose, Shower
010	201011	285655		Clamp, Hose
011	212276	W10116760		Screw
"	22002027	74007164		Lock- Purs
012	22003045			Cord, Power
013	22003223			Grommet, Cord

014	912365	3370225	Screw
015	22002551		Hose, Bleach
016	22002552		Hose, Fabric Softener----NA
017	22002553		Hose, Detergent
018	12001558		Dispenser Bottom With 4 Clamps
019	22002555		Flume, Dispenser
020	22001900		Preventer, Back Flow
"	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE
021	22002908		Tube Fitting, Flexible
022	22003057		Plug, Hole
023	22002910	3400806	Screw
024	33002501		Filter, EMI

the laundry company[®]

the laundry company[®]

the laundry company[®]