


Maytag MAH20PDCXQ 08 - CABINET-FRONT (MAH20PDCXx)



Maytag Residential Maytag MAH20PDCXQ Washer Parts Parts Diagram 08 - CABINET-FRONT (MAH20PDCXx)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22002293	22003511		Insulation
"	22003639			Cabinet Assembly
"	NLA		Not Available	CABINET ASSY. (WHT)
002	213007			Xfor Cabinet See Cabinet, Back
003	315471	22003298		Retainer, Wire
004	33001836			Strap, Top Cover Support
005	22002100			Spring
006	22002297			Support, Spring
007	22001997			Spacer, Top Cover
008	22002049			Clip Note: Clip, Front Panel
009	22002090			Brace, Corner
"	22002292			Brace, Corner
"	22003637			BRACE ASSEMBLY, TOP CROSS CONTAINS ITEMS 12 & 13
010	22001995			Screw Note: Screw, Tumbler Front And Shroud

011	22002001		Support, Hinge
012	22002247	33002597	Hook, Security
013	22002034	22003224	Bracket, Shroud
014	22002035	22002985	Bracket, Shroud
015	22001993		Bridge, Shroud Support
"	22003638	22003652	Shroud Support Assembly
016	22002259	22002767	Brace, Cross
"	22003638	22003652	Shroud Support Assembly
017	22001995		Screw Note: Screw, Tumbler Front And Shroud
018	22001996	3370225	Screw
"	22002178		Bracket, Air Dome Hose
019	22001995		Screw Note: Screw, Tumbler Front And Shroud

the laundry company[®]

Howes
the laundry company[®]

Howes
the laundry company[®]