


**Maytag MAH20PDCXW 07 - DOOR SHROUD & DOOR LATCH ASSY(MAH20PDCX)**



Maytag Residential Maytag MAH20PDCXW Washer Parts Parts Diagram 07 - DOOR SHROUD & DOOR LATCH ASSY(MAH20PDCX)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	LATCH, ASSY. (DOM/COMMERCIAL)
002	22003637			BRACE ASSEMBLY, TOP CROSS CONTAINS ITEMS 12 & 13
"	33002202	<a href="#">33002477</a>		Support, Door Lock
003	<a href="#">22001995</a>			Screw Note: Screw, Tumbler Front And Shroud
004	<a href="#">22002014</a>			Clip, Harness To Support
005	22002095	<a href="#">12001994</a>		Cover
"	<a href="#">33001764</a>			Cover, Hinge Hole
"	<a href="#">33001846</a>			Screw, Hinge Hole Cover
"	<a href="#">33002349</a>			Cover, Hinge Hole
006	<a href="#">22002506</a>			Shroud And Dispenser Hose
007	<a href="#">22003722</a>			Switch Holder Assembly, Latch
008	<a href="#">22003719</a>			Screw, Latch

009	<a href="#">22003720</a>		Nut, Latch
010	<a href="#">22002957</a>		Cover, Latch Assembly
011	22002435	<a href="#">241877</a>	Screw
012	<a href="#">22003055</a>		Ramp, Door Hoop
013	<a href="#">22002164</a>		Cable, Door
014	<a href="#">22003715</a>		Sliding Gear, Latch
015	<a href="#">22003721</a>		Spring, Axle / Latch
016	<a href="#">22003718</a>		Axle, Latch
017	<a href="#">22002119</a>		Motor, Wax
018	<a href="#">22003716</a>		Rotating Gear, Latch
019	<a href="#">22003717</a>		Spring, Latch
020	<a href="#">22001352</a>		Screw, Check Switch
021	<a href="#">22002165</a>		Washer, Door Lock Switch
022	<a href="#">22002162</a>		Switch, Door Lock Spin Enable
023	<a href="#">22002158</a>		Spring, Gear Return

