


Maytag MAH21PDA3W 05 - CONTROL PANEL



Maytag [Residential Maytag MAH21PDA3W Washer Parts](#) Parts Diagram 05 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22003688	22004349		Facia - Pd/Ps
002	215506			Screw, Control Panel Overlay
003	205810			Wire, Ground
004	206808	W10135389		Push Button And Switch Assembly
"	215527	W10140652		Screw, 6-20 X 1/2
005	215517	W10131113		Push Button
006	22003676			Switch Brkt And Back Brkt
007	22003048	22003602		Bracket- P
"	912365	3370225		Screw
008	22003049	22003725		Nut, 8mm
009	22003089			Console
010	22001996	3370225		Screw
011	215003			Fastener, Panel And Bracket
012	22001960			Transformer
013	211251			Screw, Transformer
014	22001419			Nut, Transformer

015	22004245		Board, Control PD-Japan
016	912077		Locknut, Reader Harness
017	33001204		Stand-Off, Ccontrol Board
018	22003790		Harness, Wire
019	22002954		Deflector, Water
020	211252		Screw, Ground Wire
021	215526		Screw, Circuit Board
022	215527	W10140652	Screw, 6-20 X 1/2
023	22001962	W10131114	Cover, Display
024	22002971	22004171	Relay Board OPL
025	22002943		Stand-Off
026	22003047		Filter, Power Line
"	22003050		Wire, Ground

the laundry company[®]

the laundry company[®]

the laundry company[®]