


# Maytag MAH21PDA3W 07 - TOP



Maytag Residential Maytag MAH21PDA3W Washer Parts Parts Diagram 07 - TOP  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22003586	<a href="#">22004178</a>		Cover, Top
"	<a href="#">22004178</a>			Cover, Top
002	<a href="#">22002265</a>			Cup, Siphon
003	<a href="#">22002909</a>			Lid, Dispenser
"	22002910	<a href="#">3400806</a>		Screw
004	<a href="#">22003665</a>			Bezel, Dispenser
005	Y912678	<a href="#">6-912678</a>		Pin- Hinge
006	<a href="#">Y912679</a>			Pin, Hinge
007	22002230	<a href="#">400021-1</a>		Screw
008	22002910	<a href="#">3400806</a>		Screw
009	<a href="#">22003259</a>			Hose, Shower
010	<a href="#">33002501</a>			Filter, EMI
011	212276	<a href="#">W10116760</a>		Screw
"	22002027	<a href="#">74007164</a>		Lock- Purs
012	<a href="#">22003045</a>			Cord, Power
013	<a href="#">22003223</a>			Grommet, Cord

014	912365	<a href="#">3370225</a>	Screw
015	205161	<a href="#">489503</a>	Clamp
"	<a href="#">22002551</a>		Hose, Bleach
016	205161	<a href="#">489503</a>	Clamp
"	<a href="#">22002552</a>		Hose, Fabric Softener---NA
017	205161	<a href="#">489503</a>	Clamp
"	<a href="#">22003260</a>		Extension, Nozzle
018	<a href="#">22003322</a>		Top, Dispenser
"	<a href="#">22003723</a>		Bottom, Dispenser
019	<a href="#">22003321</a>		Grid, Dispenser
020	<a href="#">22003057</a>		Plug, Hole
021	<a href="#">22002908</a>		Tube Fitting, Flexible
022	<a href="#">22002266</a>		Cap, Siphon

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>