


Maytag MAT10CSEGL 01 - CONTROL PANEL



Maytag Residential Maytag MAT10CSEGL Washer Parts Parts Diagram 01 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22001307			Panel, Control
"	NLA		Not Available	PANEL, CONTROL (W/LENS)
002	215506			Screw, Control Panel Overlay
003	204807			Ground Wire, Supp. Plte To Top Cover
004	210186	3370225		Screw
005	205353			Switch, DiAl-A-FABRIC
006	215570	22001592		(WHT)
"	22001592			(WHT)
"	NLA		Not Available	(ALM)
007	22001308			Switch, Water Level
008	212942	22001619		Tube, Water Level Switch
009	410296	596669		Clamp, Manifold
010	206780			Control Cover Assembly
"	206780L	206780		Control Cover Assembly
011	212276	W10116760		Screw
012	215003			Fastener, Panel And Bracket

013	215564		Lens, Indicator Light
014	206882	W10133276	Indicator, Five Light
015	206894		Knob, Selector
"	215561	206894	Knob, Selector
016	Y313588	488234	Screw 8-32 X 1/4
017	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
018	22001093		Wire Harness, Main

