


Maytag MAT12PDCBL 02 - CONTROL PANEL



Maytag Residential Maytag MAT12PDCBL Washer Parts Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22001958	22004305		Facia, Pd/Ps
002	215506			Screw, Control Panel Overlay
003	22001959			Wire, Ground
004	206808	W10135389		Push Button And Switch Assembly
"	215526			Screw, Circuit Board
005	215517	W10131113		Push Button
006	22001961			Bracket, Back
"	22001964	22002904		Bracket, Back
"	22002904			Bracket, Back
007	22001308			Switch, Water Level
008	22001619			Tube, Water Level Switch
009	410296	596669		Clamp, Manifold
010	206780			Control Cover Assembly
"	206780L	206780		Control Cover Assembly
"	22002884			Console
011	212276	W10116760		Screw

012	215003		Fastener, Panel And Bracket
013	206421		Relay, Motor Reversing
"	206824	W10133335	Relay, Motor
014	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	22001960		Transformer
"	Y313559		Screw
015	22001511	22002954	Deflector, Water
"	22001955	22004222	Commercial D.C. Control Board
"	33001204		Stand-Off, Ccontrol Board
"	912077		Locknut, Reader Harness
016	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
017	22001963		Wire Harness, Main
"	22002699	902577	Capacitor, Thermostat
"	22002986		Wire Harness, Main
"	314531		Connector, Edgeborard
"	Y312953		Terminal, Edgeboard
018	214610		Bumper, Lid
019	22001962	W10131114	Cover, Display
020	210186	3370225	Screw
021	215527	W10140652	Screw, 6-20 X 1/2
022	22001965		Optic Switch Assembly
"	NLA	Not Available	CONNECTOR, EDGEBOARD- --NA
023	22001361		Connector, Edgeboard
"	22001966		Harness, Sensor Switch
"	Y352890	Not Available	CABLE TIE (HDWR.PKG.)

the laundry company[®]

the laundry company[®]