


Maytag MAT12PDSAW 01 - CONTROL PANEL



Maytag Residential Maytag MAT12PDSAW Washer Parts Parts Diagram 01 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22004058			Control Panel, Facia
"	22004287		Not Available	FACIA - PD
"	22004305			Facia, Pd/Ps
002	215506			Screw, Control Panel Overlay
003	22001959			Wire, Ground
004	206808	W10135389		Push Button And Switch Assembly
"	215526			Screw, Circuit Board
005	215517	W10131113		Push Button
006	22003099			Bracket, Back
007	22001308			Switch, Water Level
008	22001619			Tube, Water Level Switch
009	22003295	285655		Clamp, Hose
010	22003091			Console
011	212276	W10116760		Screw
012	215003			Fastener, Panel And Bracket
013	206421			Relay, Motor Reversing

"	206824	W10133335	Relay, Motor
014	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	22001960		Transformer
"	Y313559		Screw
015	22002954		Deflector, Water
"	22004048	22004222	Commercial D.C. Control Board
"	33001204		Stand-Off, Ccontrol Board
"	912077		Locknut, Reader Harness
016	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
017	22004056		WIRE HARNESS
"	22004396		Harness, Wire
018	214610		Bumper, Lid
019	22001962	W10131114	Cover, Display
020	210186	3370225	Screw
021	215527	W10140652	Screw, 6-20 X 1/2
022	22001965		Optic Switch Assembly
023	22001966		Harness, Sensor Switch

