


Maytag MAT12PDSAW 05 - TUB



Maytag Residential Maytag MAT12PDSAW Washer Parts Parts Diagram 05 - TUB
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	208543			Agitator
002	212942	22001619		Tube, Water Level Switch
003	211130			Bearing Liner, Tub Bearing
004	200744	W10175939		Bolt
"	205254	W10175938		Bolt
005	22001970			Cover Assembly, Top
006	Y22001201	22001007		Gasket, Cover To Tub
007	22204012	6-2095720		Mounting S
008	211641			Clamp, 1-1/16"
009	22001142			Ring, Balance
010	22003295	285655		Clamp, Hose
011	211047	6-2110472		Nut- Clamp
012	215532			Cap, Agitator
013	211100			Washer, Outer Tub
014	215980			Plug, Filter Hole
015	Y212989			Hose, Outer Tub To Pump

016	22001640	285655	Clamp, Hose
017	206478	Not Available	SCREW & WASHER FOR AGITATOR
018	22001423		Set Screw, Mounting Stem
019	22001640	285655	Clamp, Hose
020	211210		Washer, Clamping Nut
021	200824	6-2040130	Tub Bearin
022	204013	6-2040130	Tub Bearin
023	22001141	Y2201881	Tub, Inner Short White SP
024	22001115	22003312	Tub, Outer
025	Y054867		Washer, Lock


the laundry company[®]


the laundry company[®]


the laundry company[®]