


Maytag MAT26PCABG 05 - TUB-INNER & OUTER



12

Maytag Residential Maytag MAT26PCABG Washer Parts Parts Diagram 05 - TUB-INNER & OUTER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	215532			Cap, Agitator
002	207119	207228		Agitator W/Lock Screw
"	207228			Agitator W/Lock Screw
003	206478		Not Available	SCREW & WASHER FOR AGITATOR
004	211100			Washer, Outer Tub
005	Y054867			Washer, Lock
006	204013	6-2040130		Tub Bearin
007	200824	6-2040130		Tub Bearin
008	211130			Bearing Liner, Tub Bearing
009	204012	6-2095720		Mounting S
010	211047	6-2110472		Nut- Clamp
011	Y0A4298	6-0A57420		Seal- Agitator
012	Y015667			Retaining Ring
013	Y015666			Washer, Retaining -
014	211210			Washer, Clamping Nut
015	NLA		Not Available	TUB, INNER

016	205486	Not Available	PART NOT USED
017	214739	596669	Clamp, Manifold
018	214725		Cap For Spout-Outer Tub
019	202574	3367052	Clamp, Hose
020	Y212989		Hose, Outer Tub To Pump
021	200900	616099	Clamp
022	211641		Clamp, 1-1/16"
023	200744	W10175939	Bolt
"	205254	W10175938	Bolt
024	212942	22001619	Tube, Water Level Switch
025	410296	596669	Clamp, Manifold
026	215980		Plug, Filter Hole

the laundry company[®]

the laundry company[®]

the laundry company[®]