


# Maytag MAT26PCABL 06 - TRANSMISSION



14

Maytag [Residential Maytag MAT26PCABL Washer Parts](#) Parts Diagram 06 - TRANSMISSION  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	206708	<a href="#">6-2097790</a>		Transmison
002	207153	<a href="#">6-2097820</a>		Kit- Shaft
003	206713	<a href="#">6-2067130</a>		Gear- Beve
004	<a href="#">215581</a>			Spring, Agitator Shaft
005	206685	<a href="#">6-2066850</a>		Yoke
006	<a href="#">206628</a>			Cover, Transmission
007	215417		Not Available	SCREW, TRANSMISSION COVER
008	215415		Not Available	COLLAR, LOWER
009	215401	<a href="#">W10221114</a>		Pinion
010	<a href="#">215395</a>			Plate, Clutch
011	211483	<a href="#">6-2114830</a>		Washer- SP
012	<a href="#">Y206629</a>			Pin, Collar
013	NLA		Not Available	SHAFT, CENTER
014	211059	<a href="#">6-2301530</a>		Pulley
015	<a href="#">211089</a>			Lug, Stop Pulley
016	211375	<a href="#">681582</a>		Screw

017	211090	<a href="#">22003555</a>	Washer, Stop Lug
018	206602	<a href="#">207843</a>	Lip Seal Repair Kit
019	<a href="#">215394</a>		Washer, Bevel Gear
020	206625	<a href="#">6-2097790</a>	Transmison
021	Y058700	<a href="#">675652</a>	Adhesive
022	<a href="#">210690</a>		Seal, Rubber
023	<a href="#">215532</a>		Cap, Agitator
024	206478	Not Available	SCREW & WASHER FOR AGITATOR
025	207119	<a href="#">207228</a>	Agitator W/Lock Screw

