


# Maytag MAV4500AWW 03 - CONTROL PANEL



Maytag Residential Maytag MAV4500AWW Washer Parts Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">22001664</a>			Timer Knob Insert/Cap
2	<a href="#">211605</a>			Bezel, Timer Dial
3	<a href="#">22001659</a>			Timer Knob - Grey
4	<a href="#">211065</a>			Spring, Index Wheel
5	<a href="#">22001660</a>			Dial Skirt - White
6	<a href="#">22002727</a>			Wire Harness
7	22003060	<a href="#">22002948</a>		Panel, Control
8	33002286		Not Available	CONSOLE (WHT)
9	<a href="#">22002706</a>			Switch, Pressure
"	22003461		Not Available	PAD, PRESSURE SWITCH
10	<a href="#">22002714</a>			Switch, Temperature
11	22002743	<a href="#">22003422</a>		Hose, Air Dome
"	22003237	<a href="#">22003422</a>		Hose, Air Dome
"	<a href="#">22003422</a>			Hose, Air Dome
12	<a href="#">22001789</a>			Button, Switch
"	<a href="#">22001788</a>			Button, Switch

13

[22002715](#)

Timer

"

22001661

[3400094](#)

Screw, 10-32 X 3/8

14

22002529

Not Available

CONSOLE BACK PANEL

15

22002951

Not Available

MANUAL, USE & CARE

