


Maytag MAV5758EWW 03 - CONTROL PANEL & TOP



Maytag [Residential Maytag MAV5758EWW Washer Parts](#) Parts Diagram 03 - CONTROL PANEL & TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	21002224			Screw
2	21001527			Shield, Rear
3	21001523			Endcap
4	22003977	74010226		Switch, Rocker W/Shield
5	21001519			Endcap
6	Y2201474			Switch, Pressure
7	21002071			Knob, Selector
8	37001265			Encoder, Rotary 2 Position
9	37001263			Encoder, Rotary 4 Position
10	35-2378	12002749		Hose, Flume Kit
"	12002749			Hose, Flume Kit
11	21002100	21002238		Washer Control Board
12	37001181			Knob Assembly
13	12002667			Facia As Pack
14	37001166			Support, Switch -White
15	35-0581			Bumper, Door

16	21001148	12001187	Kit, Lid Switch Assembly
17	25-7893		Screw
18	35-2044		Hinge, Lid
19	21001827		Value, Water
20	31001721		Screw, Abno.8-18 x 3/8 Hxws
21	35-2026		Lid
22	35-2846		Hinge, Cabinet Top
23	25-7732	681414	Screw, 10AB X 1/2
24	35-4128		Pad, Hinge
25	21001760		Flume Assembly / Water Diverter
26	25-7893		Screw
27	21001602		Top, Cabinet
28	21001134		Lever, Lid Switch
29	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
30	31001560		Washer, Roller
31	21001857		Clip, Plastic Snap-In
32	31001721		Screw, Abno.8-18 x 3/8 Hxws
33	21001597		Dispenser, Bleach
34	25-7438		Screw
35	31001721		Screw, Abno.8-18 x 3/8 Hxws
36	21001135		Housing, Lid Switch
37	21001136	3400872	Screw, 8-18 X 3/8
38	43-0057		Actuator, Door Switch
39	25-7430		Clip, Wiring Harness
40	35-2045		Pin, Hinge
41	37001266		Encoder, Rotary 32 Position

the laundry company[®]

lows
the laundry company[®]