


Maytag MAV5960AWW 04 - CONTROL PANEL



Maytag Residential Maytag MAV5960AWW Washer Parts Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001664			Timer Knob Insert/Cap
2	22002997			Pin, Locking
"	211605			Bezel, Timer Dial
3	22001659			Timer Knob - Grey
"	22002996	22003952		Knob, Timer
4	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
"	211065			Spring, Index Wheel
5	22001660			Dial Skirt - White
"	22002995		Not Available	SKIRT, TIMER KNOB (WHT)
6	22002819			Wire Harness
"	22003381			Harness, Main
7	22003317			Panel, Control
8	33002286		Not Available	CONSOLE (WHT)
9	22003461		Not Available	PAD, PRESSURE SWITCH
"	22002706			Switch, Pressure
10	22001789			Button, Switch

"	22001788		Button, Switch
"	22002714		Switch, Temperature
"	22002999		Switch
11	22003422		Hose, Air Dome
12	22001789		Button, Switch
"	22003387	22003388	Switch, 3 Pos. Option
"	22001788		Button, Switch
"	22002821		Switch, Option
13	22003371		Timer RPR
"	Y22002339	8534058	Screw
14	22002529	Not Available	CONSOLE BACK PANEL
"	22002782		Pad, Foam
15	16009485	Not Available	MANUAL, SERVICE-NO REFUND
"	22002750	Not Available	MANUAL, USE & CARE
"	22003861	Not Available	USER GUIDE
"	22002749	Not Available	MANUAL, USE & CARE (FRENCH)

