


# Maytag MAV6357AWW 03 - CONTROL PANEL



Maytag [Residential Maytag MAV6357AWW Washer Parts](#) Parts Diagram 03 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">22001664</a>			Timer Knob Insert/Cap
2	<a href="#">22002997</a>			Pin, Locking
3	22002996	<a href="#">22003952</a>		Knob, Timer
4	22002995		Not Available	SKIRT, TIMER KNOB (WHT)
5	<a href="#">22002999</a>			Switch
6	22003575	<a href="#">22003906</a>		Analog Temp Control Board-Assembly
7	22003397	<a href="#">22002823</a>		Panel, Control
8	22002925	<a href="#">3370225</a>		Screw
"	33002286		Not Available	CONSOLE (WHT)
9	22003461		Not Available	PAD, PRESSURE SWITCH
"	<a href="#">22002706</a>			Switch, Pressure
10	22003385		Not Available	SWITCH, (4 BUTTON TEMP) (WHT)
11	22003237	<a href="#">22003422</a>		Hose, Air Dome
12	<a href="#">22001948</a>			Lens, Indicator Light
"	<a href="#">903115</a>			Lock Light

13	<a href="#">22003371</a>		Timer RPR
14	22002529	Not Available	CONSOLE BACK PANEL
"	Y22002339	<a href="#">8534058</a>	Screw
15	<a href="#">22003003</a>		Bracket, Atc / Timer

