


Maytag MAV7258AWQ 03 - CONTROL PANEL



Maytag [Residential Maytag MAV7258AWQ Washer Parts](#) Parts Diagram 03 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	33002347			Timer Knob Insert/Cap
2	22002997			Pin, Locking
3	22002996	22003952		Knob, Timer
4	22003005	27001191		Skirt, Timer Knob
5	22003006			Switch,
6	22003562			Harness, Wire
7	22003566			Panel, Control
8	33002327	37001115		Console
"	22002925	3370225		Screw
9	22002804			Switch, Pressure
"	22003461		Not Available	PAD, PRESSURE SWITCH
10	22003006			Switch,
11	22003237	22003422		Hose, Air Dome
12	22002697			Button, Switch
"	22002698	22003875		Button- SW
13	22003561			Timer

14	Y22002339	8534058	Screw
"	22002529	Not Available	CONSOLE BACK PANEL
15	22003003		Bracket, Atc / Timer
16	22003575	22003906	Analog Temp Control Board-Assembly
"	22002857	22003906	Analog Temp Control Board-Assembly
17	903115		Lock Light
"	22001948		Lens, Indicator Light
18	22003493		Switch, Rinse Opt
19	22003472	22003866	User Guide
"	16009485	Not Available	MANUAL, SERVICE-NO REFUND

the laundry company[®]

the laundry company[®]

the laundry company[®]