


Maytag MAV7258AWW 03 - CONTROL PANEL



Maytag [Residential Maytag MAV7258AWW Washer Parts](#) Parts Diagram 03 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	22001664			Timer Knob Insert/Cap
2	22002997			Pin, Locking
3	22002996	22003952		Knob, Timer
4	22002995		Not Available	SKIRT, TIMER KNOB (WHT)
5	22002999			Switch
6	22003562			Harness, Wire
7	22003565			Panel, Control
8	22002925	3370225		Screw
"	33002286		Not Available	CONSOLE (WHT)
9	22002705			Switch, Pressure
"	22003461		Not Available	PAD, PRESSURE SWITCH
10	22003385		Not Available	SWITCH, (4 BUTTON TEMP) (WHT)
11	22003237	22003422		Hose, Air Dome
12	22001788			Button, Switch
"	22001789			Button, Switch
13	22003561			Timer

14	Y22002339	8534058	Screw
"	22002529	Not Available	CONSOLE BACK PANEL
15	22003003		Bracket, Atc / Timer
16	22003575	22003906	Analog Temp Control Board-Assembly
"	22002857	22003906	Analog Temp Control Board-Assembly
17	903115		Lock Light
"	22001948		Lens, Indicator Light
18	22003492		Switch, Rinse Opt
19	22003472	22003866	User Guide
"	16009485	Not Available	MANUAL, SERVICE-NO REFUND

the laundry company[®]

the laundry company[®]

the laundry company[®]