


Maytag MAV7358AWQ 03 - CONTROL PANEL



Maytag [Residential Maytag MAV7358AWQ Washer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33002347			Timer Knob Insert/Cap
2	22002997			Pin, Locking
3	22002996	22003952		Knob, Timer
4	22003005	27001191		Skirt, Timer Knob
5	22003006			Switch,
6	22003860			Switch, Push Button / Bisque
7	22003868	22003865		Control Panel, Facia - BSQ
8	22002925	3370225		Screw
"	33002327	37001115		Console
9	22003461		Not Available	PAD, PRESSURE SWITCH
"	22002804			Switch, Pressure
10	22002814			Switch, 4 Button Option / BSQ
11	22003237	22003422		Hose, Air Dome
12	22001948			Lens, Indicator Light
"	903115			Lock Light
13	22003561			Timer

14	22002529	Not Available	CONSOLE BACK PANEL
"	Y22002339	8534058	Screw
15	22003003		Bracket, Atc / Timer
16	22003575	22003906	Analog Temp Control Board- Assembly

