


# Maytag MAV7358AWW 03 - CONTROL PANEL



Maytag [Residential Maytag MAV7358AWW Washer Parts](#) Parts Diagram 03 - CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">22001664</a>			Timer Knob Insert/Cap
2	<a href="#">22002997</a>			Pin, Locking
3	22002996	<a href="#">22003952</a>		Knob, Timer
4	22002995		Not Available	SKIRT, TIMER KNOB (WHT)
5	<a href="#">22002999</a>			Switch
6	<a href="#">22003859</a>			Switch, Push Button / White
7	22003867	<a href="#">22003863</a>		Control Panel, Facia - White
8	33002286		Not Available	CONSOLE (WHT)
"	22002925	<a href="#">3370225</a>		Screw
9	22003461		Not Available	PAD, PRESSURE SWITCH
"	<a href="#">22002705</a>			Switch, Pressure
10	22002711		Not Available	SWITCH, 4 BUTTON OPTION / WHT
11	22003237	<a href="#">22003422</a>		Hose, Air Dome
12	<a href="#">22001948</a>			Lens, Indicator Light
"	<a href="#">903115</a>			Lock Light
13	<a href="#">22003561</a>			Timer

14	22002529		Not Available	CONSOLE BACK PANEL
"	Y22002339	<a href="#">8534058</a>		Screw
15	<a href="#">22003003</a>			Bracket, Atc / Timer
16	22003575	<a href="#">22003906</a>		Analog Temp Control Board- Assembly

