


Maytag MAV7580EWW 03 - CONTROL PANEL



Maytag Residential Maytag MAV7580EWW Washer Parts Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001664			Timer Knob Insert/Cap
2	22002997			Pin, Locking
3	22002996	22003952		Knob, Timer
4	22002995		Not Available	SKIRT, TIMER KNOB (WHT)
5	22002999			Switch
6	22003738			Harness, Wire
7	22003741	22003736		Panel, Control
8	22002925	3370225		Screw
"	33002286		Not Available	CONSOLE (WHT)
9	22003489			Switch, Pressure
"	22003461		Not Available	PAD, PRESSURE SWITCH
10	22003739			Switch, 4 Button Option
11	22003237	22003422		Hose, Air Dome
"	22003422			Hose, Air Dome
12	22001789			Button, Switch
"	22001788			Button, Switch

13	22003499		Timer RPR
"	22003370	22003499	Timer RPR
14	22002529		Not Available
			CONSOLE BACK PANEL
"	Y22002339	8534058	Screw
15	22003003		Bracket, Atc / Timer
16	22003743	22004106	Temp Control Board
17	903115		Lock Light
"	22001948		Lens, Indicator Light
18	22003745		Energy Guide
"	16009485		Not Available
			MANUAL, SERVICE-NO REFUND
19	16022156		Not Available
			USE & CARE GUIDE
20	20001120	THP-1	Hose Pliers
21	22002898		Tool, Seal Nut
22	22002922		Tool, Spring Removal
23	35-2968		Not Available
			SPANNER WRENCH BASKET DRIVE HU

