


Maytag MAV8057AWQ 03 - CONTROL PANEL



Maytag [Residential Maytag MAV8057AWQ Washer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33002347			Timer Knob Insert/Cap
2	211605			Bezel, Timer Dial
3	22001659			Timer Knob - Grey
4	211065			Spring, Index Wheel
5	22002598	22003920		Dial Skirt
6	22002834			Wire Harness
"	22003221			Wire Harness
7	22002832			Panel, Control
8	22002815			Switch, Rocker
9	22002816			Switch, Rocker
10	33002327	37001115		Console
11	22002804			Switch, Pressure
"	22003461		Not Available	PAD, PRESSURE SWITCH
12	22002698	22003875		Button- SW
"	22002746			Switch, Temperature
"	22002697			Button, Switch

13	22002697		Button, Switch
"	22002698	22003875	Button- SW
"	22002811		Switch,
14	22002698	22003875	Button- SW
"	22002814		Switch, 4 Button Option / BSQ
"	22002697		Button, Switch
15	22003219		Timer
"	22002718		Timer
"	22001661	3400094	Screw, 10-32 X 3/8
16	22003422		Hose, Air Dome
"	22003237	22003422	Hose, Air Dome
"	22002743	22003422	Hose, Air Dome
17	22002529	Not Available	CONSOLE BACK PANEL
18	22002858	22003617	Control-Elec
19	22002856		Bracket, Mtg.
20	22001948		Lens, Indicator Light
"	903115		Lock Light
21	22002813	Not Available	MANUAL, USE & CARE (FRENCH)
"	22002812	Not Available	MANUAL, USE & CARE
"	16009485	Not Available	MANUAL, SERVICE-NO REFUND
"	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG

