


# Maytag MAV8057AWW 03 - CONTROL PANEL



Maytag [Residential Maytag MAV8057AWW Washer Parts](#) Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">22001664</a>			Timer Knob Insert/Cap
2	<a href="#">211605</a>			Bezel, Timer Dial
3	<a href="#">22001659</a>			Timer Knob - Grey
4	<a href="#">211065</a>			Spring, Index Wheel
5	<a href="#">22001660</a>			Dial Skirt - White
6	<a href="#">22002834</a>			Wire Harness
"	<a href="#">22003221</a>			Wire Harness
7	<a href="#">22002833</a>			Panel, Control
8	22002719	<a href="#">22002815</a>		Switch, Rocker
9	<a href="#">22002720</a>			Switch, Rocker
10	33002286		Not Available	CONSOLE (WHT)
11	<a href="#">22002705</a>			Switch, Pressure
"	22003461		Not Available	PAD, PRESSURE SWITCH
12	<a href="#">22001789</a>			Button, Switch
"	<a href="#">22002714</a>			Switch, Temperature
"	<a href="#">22001788</a>			Button, Switch

13	<a href="#">22001788</a>		Button, Switch
"	<a href="#">22001789</a>		Button, Switch
"	22002711	Not Available	SWITCH, 4 BUTTON OPTION / WHT
14	22002711	Not Available	SWITCH, 4 BUTTON OPTION / WHT
"	<a href="#">22001788</a>		Button, Switch
"	<a href="#">22001789</a>		Button, Switch
15	<a href="#">22002718</a>		Timer
"	22001661	<a href="#">3400094</a>	Screw, 10-32 X 3/8
"	<a href="#">22003219</a>		Timer
16	22002743	<a href="#">22003422</a>	Hose, Air Dome
"	<a href="#">22003422</a>		Hose, Air Dome
"	22003237	<a href="#">22003422</a>	Hose, Air Dome
17	22002529	Not Available	CONSOLE BACK PANEL
18	22002858	<a href="#">22003617</a>	Control-Elec
19	<a href="#">22002856</a>		Bracket, Mtg.
20	<a href="#">22001948</a>		Lens, Indicator Light
"	<a href="#">903115</a>		Lock Light
21	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG
"	16009485	Not Available	MANUAL, SERVICE-NO REFUND
"	22002812	Not Available	MANUAL, USE & CARE
"	22002813	Not Available	MANUAL, USE & CARE (FRENCH)

