


Maytag MAV8500AWW 03 - CONTROL PANEL



Maytag [Residential Maytag MAV8500AWW Washer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22001664			Timer Knob Insert/Cap
2	22002997			Pin, Locking
3	22001659			Timer Knob - Grey
4	22002995		Not Available	SKIRT, TIMER KNOB (WHT)
5	22001948			Lens, Indicator Light
6	22003002			Wire Harness, Main
7	22003001	22003507		Panel, Control
8	22002719	22002815		Switch, Rocker
9	22002720			Switch, Rocker
10	33002286		Not Available	CONSOLE (WHT)
11	22002705			Switch, Pressure
"	22003461		Not Available	PAD, PRESSURE SWITCH
12	22001789			Button, Switch
"	22002999			Switch
"	22001788			Button, Switch
13	22001788			Button, Switch

"	22001789		Button, Switch
"	22003000		Switch
14	22002711	Not Available	SWITCH, 4 BUTTON OPTION / WHT
"	22001788		Button, Switch
"	22001789		Button, Switch
15	22002998		Timer
"	22001661	3400094	Screw, 10-32 X 3/8
16	22003237	22003422	Hose, Air Dome
"	22003422		Hose, Air Dome
"	22002743	22003422	Hose, Air Dome
17	22002529	Not Available	CONSOLE BACK PANEL
18	22003009	22003617	Control-Elec
19	22003003		Bracket, Atc / Timer
20	903115		Lock Light
21	16009485	Not Available	MANUAL, SERVICE-NO REFUND
"	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG

