


Maytag MAV8600AWW 04 - CONTROL PANEL



Maytag Residential Maytag MAV8600AWW Washer Parts Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|--------------------------|---------------|-------------------------|
| 1 | 22001664 | | | Timer Knob Insert/Cap |
| 2 | 22002997 | | | Pin, Locking |
| 3 | 22002996 | 22003952 | | Knob, Timer |
| 4 | 22002995 | | Not Available | SKIRT, TIMER KNOB (WHT) |
| 5 | 22002999 | | | Switch |
| 6 | 22003382 | | | Harness, Main |
| 7 | 22003407 | 22003507 | | Panel, Control |
| " | 22003507 | | | Panel, Control |
| 8 | 22002925 | 3370225 | | Screw |
| " | 33002286 | | Not Available | CONSOLE (WHT) |
| 9 | 22002705 | | | Switch, Pressure |
| " | 22003461 | | Not Available | PAD, PRESSURE SWITCH |
| 10 | 22003000 | | | Switch |
| 11 | 22003422 | | | Hose, Air Dome |
| " | 22003237 | 22003422 | | Hose, Air Dome |
| 12 | 22001788 | | | Button, Switch |

| | | | |
|----|--------------------------|--------------------------|-------------------------------|
| " | 22001789 | | Button, Switch |
| 13 | 22003500 | | Timer |
| " | 22003394 | 22003500 | Timer |
| 14 | 22002529 | | Not Available |
| " | Y22002339 | 8534058 | CONSOLE BACK PANEL |
| | | | Screw |
| 15 | 22003003 | | Bracket, Atc / Timer |
| 16 | 22003009 | 22003617 | Control-Elec |
| 17 | 22001948 | | Lens, Indicator Light |
| " | 903115 | | Lock Light |
| 18 | 22002814 | | Switch, 4 Button Option / BSQ |
| 19 | 22002719 | 22002815 | Switch, Rocker |
| 20 | 22002720 | | Switch, Rocker |
| 21 | 22003352 | | Not Available |
| " | 16009485 | | Not Available |
| | | | MANUAL, USE & CARE (TRI) |
| | | | MANUAL, SERVICE-NO REFUND |

