


Maytag MAVT754EWW 03 - CONTROL PANEL & TOP



Maytag Residential Maytag MAVT754EWW Washer Parts Parts Diagram 03 - CONTROL PANEL & TOP
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	22003955			Switch Support
2	22003960		Not Available	CONSOLE HOUSING (WHT)
3	22003938	8534058		Screw
4	22002754			Plunger
5	22002757			Guide Tube
6	22003941			Lid Cam
7	22004346	22004070		Timer
8	22002751			Hinge Pin
9	22004063			Lid As Pack Phase Iii
10	2016090			Screw, Lid Switch To Bracket
11	22003804			Lid Switch
12	22003817	3370225		Screw
13	22003938	8534058		Screw
14	22003468			Cover, Top
15	22002753			Bushing, Hinge
16	22002835			Cup, Bleach

"	22004381		Bleach Cup
17	22002967		Condensate Seal
18	22003989		Timer Cap White
19	22003993		Timer Knob
20	22004165		Timer Dial Skirt
21	22003987		Control Knob White
22	22003981		Switch, Momentary Rocker
23	22004004		5 Position Rotary Speed Switch
24	22003977	74010226	Switch, Rocker W/Shield
25	22004345		Facia/Control Panel
26	22004337		Temp Switch, 4 Pos. Rotary
27	22004069		5 Position Pressure Switch
28	33002917		Screw, No.10-16

the laundry company[®]

the laundry company[®]

the laundry company[®]