

# Maytag MDE12PSBCW 04 - DOOR



Maytag Residential Maytag MDE12PSBCW Dryer Parts Parts Diagram 04 - DOOR  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y314062</a>			Screw, Door Hinge And Panel
002	<a href="#">33001230</a>			Hinge, Door
003	<a href="#">33001240</a>			Door
004	<a href="#">33001241</a>			Handle, Door
005	<a href="#">33001131</a>			Seal, Door
006	33001132	<a href="#">33002342</a>		Plug, Sifht Hole
007	Y304578	<a href="#">LA-1003</a>		Door Catch Kit
008	<a href="#">22001650</a>			Fastener, Spring
009	<a href="#">Y310376</a>			Clip, Door Switch Harness
010	33001509	<a href="#">W10169313</a>		Switch-Dor
011	<a href="#">314937</a>			Seal, Front Panel
012	NLA		Not Available	SPEEDNUT, HINGE SCREW
"	NLA		Not Available	SCREW, PLASTIC
013	33001486	<a href="#">98008544</a>		Screw
"	NLA		Not Available	PANEL, FRONT (WHT)---NA
014	NLA		Not Available	PLUG, DOOR CATCH

015	<a href="#">33001175</a>		Cover, Hinge Hole
016	<a href="#">Y313910</a>		Clip, Door Liner To Outer Panel
017	<a href="#">22001496</a>		Front Panel Fastener And Screw
018	33001243	Not Available	PANEL, INNER DOOR (W/SEAL)
019	314944	<a href="#">33001305</a>	Strike, Door
"	<a href="#">33001305</a>		Strike, Door

