


Maytag MDE12PSBDW 01 - CONTROL PANEL



Maytag [Residential Maytag MDE12PSBDW Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33001737			Panel, Control
002	215506			Screw, Control Panel Overlay
003	22001959			Wire, Ground
004	215527	W10140652		Screw, 6-20 X 1/2
"	306694			Backup Plate With Switch
005	215517	W10131113		Push Button
006	33001736		Not Available	PLATE, BACK-UP (WHT)
007	NLA		Not Available	CONSOLE (WHT)
008	212276	W10116760		Screw
009	215003			Fastener, Panel And Bracket
010	206824	W10133335		Relay, Motor
"	Y313559			Screw
011	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	22001960			Transformer
012	33001204			Stand-Off, Ccontrol Board
"	33001738	W10130081		Control Board

"	912077		Locknut, Reader Harness
013	314531		Connector, Edgeboard
"	33001743	33001879	Wire Harness, Main
"	33001879		Wire Harness, Main
"	NLA	Not Available	WIRE HARNESS, MAIN
014	22001962	W10131114	Cover, Display
015	211252		Screw, Ground Wire
016	215526		Screw, Circuit Board
017	22001965		Optic Switch Assembly
"	NLA	Not Available	CONNECTOR, EDGEBOARD- ---NA
018	22001361		Connector, Edgeboard
"	22001966		Harness, Sensor Switch

the laundry company[®]

the laundry company[®]

the laundry company[®]