


Maytag MDE26CSACG 08 - MOTOR DRIVE, BLOWER & BASE FRAME



Maytag Residential Maytag MDE26CSACG Dryer Parts Parts Diagram 08 - MOTOR DRIVE, BLOWER & BASE FRAME
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y312961	W10116751		Screw
002	410233	9703438		Ring-Retrn
003	312967			Clamp, Blower Housing
004	Y303836			Blower Wheel Assembly And Clamp
005	Y312893			Housing, Blower
006	901220			Ground Wire
007	Y303358	W10410999		Motor-Drive
008	306207		Not Available	(PROD. No.303358-8 & No.303358-9)
"	NLA		Not Available	SWITCH, MOTOR START-PROD.
"	Y303877		Not Available	SWITCH, MOTOR EXTERNAL START No.303358-2, No.303358-4, 303358-7
"	Y303879			Switch, Motor External Start
009	Y015825			Clip, Motor To Motor Support
010	Y053241			Set Screw, Motor Pulley

011	Y305185	6-3051850	Pulley- MO
012	910343	488234	Screw 8-32 X 1/4
013	Y303945		IDLER SPRING ASSY. W/PLUG
014	Y312959		Poly "V" Belt For Tumbler
015	312958	354987	Ring, Retaining
016	Y312527		Washer, Idler Shaft
017	Y303705	6-3037050	Pulley- ID
018	Y014874		Screw, Idler Arm And Sleeve
019	Y312894	315772	Sleeve, Idler Arm
020	Y303363	6-3033630	Idler Arm
021	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
022	Y313582	W10116756	Spacer
023	NLA		Not Available
024	Y310632	1163839	SUPPORT, MOTOR
025	Y313561		Screw
026	314778		Not Available
027	Y312901		COVER, BLOWER HOUSING
028	210684		Seal, Housing Cover
029	Y302699	22003428	Foot, Adjustable Leg
030	210385		Leg, Adjustable
031	Y303361		Not Available
032	Y310376		Lock Nut For Adjustable Leg
033	Y303442		BASE ASSY. (UPPER & LOWER)
034	410490		Clip, Door Switch Harness
035	Y313262	W10116752	EXHAUST DUCT ASSEMBLY
036	306199		Spring, Retainer Wire Harness
			Retainer-
			Relay, Heater

the laundry company[®]

the laundry company[®]