


# Maytag MDE27CSACW 10 - THERMOSTATS



38

Maytag [Residential Maytag MDE27CSACW Dryer Parts](#) Parts Diagram 10 - THERMOSTATS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">Y303225</a>			Thermostat, Permanent Press
002	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">303392</a>			Thermostat, Cycling
003	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">306604</a>			Cut-Off, Thermal Part Not Used
004	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">306966</a>			Thermostat, Multi-Temp Part Not Used Mdg26ct-MN Only
005	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">306967</a>			Thermostat, Multi-Temp Part Not Used Mde26ct-MN Only
006	<a href="#">Y313561</a>			Screw----NA

