


Maytag MDE27PCACL 07 - MOTOR, BLOWER, BASE FRAME & THERMOSTATS



Maytag Residential Maytag MDE27PCACL Dryer Parts Parts Diagram 07 - MOTOR, BLOWER, BASE FRAME & THERMOSTATS

Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|--------------------------|--------|--|
| 001 | 211294 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | 306056 | | | Thermistor Temp. Control Part Not Used Mde/G26pc Only. |
| 002 | 211294 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | Y303391 | 33303391 | | Thermostat, Cycling |
| 003 | 211294 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | 303392 | | | Thermostat, Cycling |
| 004 | 410233 | 9703438 | | Ring-Retrn |
| 005 | 312967 | | | Clamp, Blower Housing |
| 006 | Y303836 | | | Blower Wheel Assembly And Clamp |
| 007 | Y312893 | | | Housing, Blower |
| 008 | 901220 | | | Ground Wire |
| " | 910343 | 488234 | | Screw 8-32 X 1/4 |

| | | | |
|-----|-------------------------|---------------------------|---|
| 009 | Y303358 | W10410999 | Motor-Drive |
| 010 | 306207 | | Not Available (PROD. No.303358-8 & No.303358-9) |
| " | NLA | | Not Available SWITCH, MOTOR START-PROD. |
| " | Y303877 | | Not Available SWITCH, MOTOR EXTERNAL START No.303358-2, No.303358-4, 303358-7 |
| " | Y303879 | | Switch, Motor External Start |
| 011 | Y015825 | | Clip, Motor To Motor Support |
| 012 | Y053241 | | Set Screw, Motor Pulley |
| 013 | Y305185 | 6-3051850 | Pulley- MO |
| 014 | Y303945 | | IDLER SPRING ASSY. W/PLUG |
| 015 | Y312959 | | Poly "V" Belt For Tumbler |
| 016 | 312958 | 354987 | Ring, Retaining |
| 017 | Y312527 | | Washer, Idler Shaft |
| 018 | Y303705 | 6-3037050 | Pulley- ID |
| 019 | Y312894 | 315772 | Sleeve, Idler Arm |
| 020 | Y014874 | | Screw, Idler Arm And Sleeve |
| " | Y303363 | 6-3033630 | Idler Arm |
| " | Y312961 | W10116751 | Screw |
| 021 | NLA | | Not Available SPACER, IDLER |
| 022 | NLA | | Not Available SUPPORT, MOTOR |
| 023 | 314847 | | COVER, BLOWER HOUSING |
| " | Y310632 | 1163839 | Screw |
| 024 | Y312901 | | Seal, Housing Cover |
| 025 | 211294 | 90767 | Screw, 8A X 3/8 HeX Washer Head Tapping |
| " | 306062 | | Transformer, Lower Dryer Base |
| " | 315218 | | Shield, Transformer |
| " | Y313559 | | Screw |
| 026 | 210684 | | Foot, Adjustable Leg |
| 027 | Y302699 | 22003428 | Leg, Adjustable |
| 028 | 210385 | | Lock Nut For Adjustable Leg |
| 029 | 306261 | | Base Assembly, Upper Dryer |
| " | Y303361 | | Not Available BASE ASSY. (UPPER & LOWER) |
| 030 | Y310376 | | Clip, Door Switch Harness |
| 031 | Y303442 | | EXHAUST DUCT ASSEMBLY |
| 032 | 410490 | | Spring, Retainer Wire Harness |
| 033 | Y313262 | W10116752 | Retainer- |

the laundry company[®]