


Maytag MDE27PCACW 02 - REAR



Maytag Residential Maytag MDE27PCACW Dryer Parts Parts Diagram 02 - REAR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
002	211881			Grommet, Cord Part Not Used-Gas Models Only
003	Y313561			Screw---NA
"	Y312905		Not Available	COVER, TERMINAL
004	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
005	Y311423	489483		Screw 10-32 X 1/2
"	Y312184			Strap, Grounding
006	400008			Block, Terminal
"	Y312209	W10001200		Screw
007	Y313561			Screw---NA
"	Y312904			Bracket, Terminal Block
008	Y311270			Washer, Terminal Block
009	311484	112432		Nut
010	307104			Top Cover Assembly

"	NLA		Not Available	(ALMOND)
011	NLA		Not Available	TOP COVER PLATE
"	Y313559			Screw
012	NLA		Not Available	SCREW & WASHER ASSY.
013	213007			Xfor Cabinet See Cabinet, Back
"	NLA		Not Available	CABINET, UPPER (WHITE)
"	Y310632	1163839		Screw
014	310933	33002194		Nut, Speed
015	NLA		Not Available	COUPLING COLLAR-WHITE
"	Y310632	1163839		Screw
016	NLA		Not Available	CABINET, LOWER (WHITE)
017	210385			Lock Nut For Adjustable Leg
018	Y302699	22003428		Leg, Adjustable
019	210684			Foot, Adjustable Leg
020	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	Y313561			Screw---NA
"	Y312951		Not Available	ACCESS COVER, BACK
021	311155			Ground Wire And Clamp
022	301548			Clamp, Ground Wire

