


# Maytag MDE3050AGW 04 - DOOR



Maytag Residential Maytag MDE3050AGW Dryer Parts Parts Diagram 04 - DOOR  
 Click on the part number to view part

| Item | Original Part Number     | Replaced By              | Status        | Part Description                                  |
|------|--------------------------|--------------------------|---------------|---|
| 1    | <a href="#">33001767</a> |                          |               | Seal, Shroud                                      |
| 2    | 22002033                 | <a href="#">33002597</a> |               | Hook, Security                                    |
| 3    | 33002116                 |                          | Not Available | LABEL, SAFTEY                                     |
| "    | <a href="#">33001778</a> |                          |               | Shroud  |
| 4    | <a href="#">22001995</a> |                          |               | Screw Note: Screw, Tumbler Front And Shroud       |
| 5    | <a href="#">33001768</a> |                          |               | Screw, Shroud Note: Screw, Shroud And Outlet Duct |
| 6    | <a href="#">33002239</a> |                          |               | Switch, Door                                      |
| 7    | <a href="#">33001760</a> |                          |               | Bracket, Hinge                                    |
| 8    | 33001174                 | <a href="#">LA-1003</a>  |               | Door Catch Kit                                    |
| 9    | 33001791                 | <a href="#">306436</a>   |               | Door Latch Kit--W                                 |
| "    | Y304578                  | <a href="#">LA-1003</a>  |               | Door Catch Kit                                    |
| 10   | <a href="#">33002094</a> |                          |               | Seal, Door  |
| 11   | <a href="#">22002038</a> |                          |               | Clip, Door  |
| 12   | <a href="#">33001793</a> |                          |               | Bracket, Strike                                   |
| 13   | <a href="#">33001761</a> |                          |               | Strike, Door                                      |

|    |                          |                          |  |
|----|--------------------------|--------------------------|--|
| 14 | <a href="#">22002039</a> |                          | Clip, Door                                 |
| 15 | <a href="#">33001763</a> |                          | Plug, Inner Door                           |
| 16 | <a href="#">22002063</a> |                          | Screw No.8-18AB Wafer Head                 |
| "  | <a href="#">22002039</a> |                          | Clip, Door                                 |
| "  | <a href="#">33001750</a> |                          | Door, Inner/ W Seal                        |
| 17 | <a href="#">22002260</a> |                          | Panel, Door                                |
| "  | <a href="#">22001817</a> |                          | Sheet, Sound Damper                        |
| "  | 33001893                 | Not Available            | LABEL, OPEN DOOR (DRYER)                   |
| 18 | <a href="#">33001759</a> |                          | Hinge, Door                                |
| 19 | 22002062                 | <a href="#">98006631</a> | Screw                                      |
| 20 | <a href="#">22002063</a> |                          | Screw No.8-18AB Wafer Head                 |
| 21 | <a href="#">33001764</a> |                          | Cover, Hinge Hole                          |
| 22 | <a href="#">33001787</a> |                          | Screw, Hinge Note: Screw, Hinge Hole Cover |
| 23 | <a href="#">22002012</a> |                          | Screw, Hinge Note: Screw, Hinge Bracket    |
| 24 | 22002241                 | <a href="#">22002836</a> | Panel, Front                               |

