


Maytag MDE5960AYW 03 - CONTROL PANEL



Maytag [Residential Maytag MDE5960AYW Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y22002339	8534058		Screw
"	33002564			Panel, Control
2	33001621			Skirt, Timer Dial
3	22001659			Timer Knob - Grey
4	22001664			Timer Knob Insert/Cap
5	33001619	37001071		Button, Push-To-Start
6	33001690	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	33001932			Timer
8	216423	3370225		Screw
"	22002529		Not Available	CONSOLE BACK PANEL
9	33002286		Not Available	CONSOLE (WHT)
10	33001861	33001618		Switch- PU
11	33001933			Wire Harness, Main
12	33001652			Switch, Temp 4 Pos
13	22001788			Button, Switch
14	22001789			Button, Switch

15	33002389		Dryness Display Control Note: Display, Dryness
16	33002391		Manual, Use And Care
"	33002450	Not Available	MANUAL, USE & CARE (SPANISH)
"	33002554	Not Available	MANUAL, USE & CARE (FRCH)

