


Maytag MDE9700AZM 03 - DRUM



Maytag [Residential Maytag MDE9700AZM Dryer Parts](#) Parts Diagram 03 - DRUM
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	35001130	W10296563		Drum
2	35001131			Baffle-Drum
3	35001132	23001661		Nut M10
4	35001133			Washer, Support
5	35001134			Drum-Back
6	35001135		Not Available	Air Duct Assembly
"	35001240			Assembly, Air-Duct
7	35001136	W10177428		Assembly, Roller-Support
8	35001137	W10205415		Belt
9	35001149			Assembly-Drum Front
10	35001138	22002263		Lamp
11	35001150			Assembly-Guide Sensor
12	6046-000310			Stand Off
13	35001139			Cover-Lamp
14	35001004	M0585401		Tie, Wire
15	35001140			Assembly, Lint Duct

16	35001141		Case-Filter
17	35001142		Cover-Filter
18	6002-001204	Not Available	SCREW-TAPPING
19	34001211		Screw-Pump Bracket
20	6002-001006	Not Available	SCREW
21	35001143		Guide-Lamp
22	35001144		Cover-Filter
23	35001145		Bracket, Upper Rear Bulkhead
24	35001146		Channel Bracket, Rear Bulkhead
25	6002-000239	Not Available	Screw-Tapping (10)
26	35001147	97001095	Screw-Motor
27	6002-001320	489355	Screw, 8 X 1/2
28	6002-000231	Not Available	Screw-Tapping (5)
29	6002-001320	489355	Screw, 8 X 1/2
30	35001148		Socket-Lamp

