


# Maytag MDG10CSAAW 02 - CONTROL CENTER



\* CONTACT YOUR COMMERCIAL LAUNDRY DISTRIBUTOR

Maytag [Residential Maytag MDG10CSAAW Dryer Parts](#) Parts Diagram 02 - CONTROL CENTER

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	206952	<a href="#">22001405</a>		Case, Coin Slide
"	206952L	<a href="#">22001405</a>		Case, Coin Slide
002	207913	<a href="#">208883</a>		Coin Box K
"	NLA		Not Available	(ALM)
003	212328	<a href="#">W10139762</a>		Hex Nut, 3/4-27
004	NLA		Not Available	STRAP, MOUNTING
005	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
006	<a href="#">910309</a>			Washer, Mounting Strap
007	<a href="#">214660</a>			Gasket, Control Center
008	Y052740	<a href="#">62739</a>		Nut, Lock
009	<a href="#">215559</a>			Bolt, Coin Slide Locking
010	<a href="#">910387</a>			Lockwasher, Vault Assembly
011	<a href="#">Y052721</a>			Nut, Terminal Block Plate
012	212328	<a href="#">W10139762</a>		Hex Nut, 3/4-27
013	213750	<a href="#">W10133266</a>		Cam-Lock
014	22001354	<a href="#">W10177242</a>		Hex-Nut 9/32 - 28

015	<a href="#">22001355</a>		Nut, Lock Cam
016	<a href="#">216203</a>		Lockwasher, Double "D"
"	NLA	Not Available	LOCK CAM ASSY. NA
017	<a href="#">33001195</a>		Wire Harness, Timer
019	204216	Not Available	DOOR, ACCESS (WHT)
"	<a href="#">204216L</a>		Door, Access
020	<a href="#">Y308109</a>		Slide And Adj. Return Bracket
021	<a href="#">33001275</a>		Torsion Timer Assembly
"	<a href="#">33002115</a>		Timer
022	314337	<a href="#">33002968</a>	Slider
023	305798	Not Available	BYPASS SWITCH FOR MOTOR
024	<a href="#">Y305799</a>		Bypass Switch For Heater
025	<a href="#">211790</a>		Lock Ring For Timer Shaft
026	<a href="#">Y312270</a>		Clip, Spring Retainer
027	314330	Not Available	DRIVER FOR INDEX WHEEL (NOT INCLUDED W/KIT)
028	<a href="#">314335</a>		Peg, Tine Adjustment
"	314547	<a href="#">Y308109</a>	Slide And Adj. Return Bracket
029	<a href="#">314339</a>		Switch And Slider Bracket
030	<a href="#">314546</a>		Wheel, Index
031	<a href="#">211065</a>		Spring, Index Wheel
032	314548	<a href="#">33002967</a>	Actuator, Switch
033	<a href="#">314334</a>		Bracket For Coin Slide
034	33001207	<a href="#">33002702</a>	Timer Bracket
035	NLA	Not Available	SPRING, HELICAL
036	<a href="#">314331</a>		Spring, Torsion Return
037	<a href="#">314332</a>		Spring, Actuator
038	<a href="#">306104</a>		Actuator Switch Kit
039	212707	<a href="#">3196385</a>	Screw
040	22001354	<a href="#">W10177242</a>	Hex-Nut 9/32 - 28
041	<a href="#">22001355</a>		Nut, Lock Cam
042	<a href="#">315277</a>		Screw
043	Y052634	<a href="#">701719</a>	Nut, Hex
044	910708	<a href="#">488234</a>	Screw 8-32 X 1/4
046	211168	<a href="#">W10139210</a>	Screw, 8-18 X 5/16

