


# Maytag MDG10CSAAW 05 - CABINET (REAR)



Maytag [Residential Maytag MDG10CSAAW Dryer Parts](#) Parts Diagram 05 - CABINET (REAR)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y312905		Not Available	COVER, TERMINAL
002	<a href="#">Y313561</a>			Screw---NA
003	210186	<a href="#">3370225</a>		Screw
"	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	33001284		Not Available	CORD, POWER
004	<a href="#">Y313561</a>			Screw---NA
"	Y310632	<a href="#">1163839</a>		Screw
005	NLA		Not Available	SCREW & WASHER ASSY.
006	<a href="#">301548</a>			Clamp, Ground Wire
007	<a href="#">204807</a>			Ground Wire, Supp. Plite To Top Cover
008	<a href="#">Y313559</a>			Screw
009	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
010	Y312951		Not Available	ACCESS COVER, BACK
011	<a href="#">Y305086</a>			Adjustable Leg And Nut

012	<a href="#">Y314137</a>		Foot, Rubber
013	Y052740	<a href="#">62739</a>	Nut, Lock
014	Y303361	Not Available	BASE ASSY. (UPPER & LOWER)
015	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
016	NLA	Not Available	CABINET (WHT)
017	<a href="#">211881</a>		Grommet, Cord Part Not Used-Gas Models Only

