


Maytag MDG10CSAGW 05 - CABINET (REAR)



Maytag [Residential Maytag MDG10CSAGW Dryer Parts](#) Parts Diagram 05 - CABINET (REAR)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y312905		Not Available	COVER, TERMINAL
002	Y313561			Screw---NA
003	210186	3370225		Screw
"	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	308966		Not Available	CORD, POWER (EXPORT)
"	33001285		Not Available	CORD, POWER
004	Y313561			Screw---NA
"	Y310632	1163839		Screw
005	NLA		Not Available	SCREW & WASHER ASSY.
006	301548			Clamp, Ground Wire
007	204807			Ground Wire, Supp. Plte To Top Cover
008	Y313559			Screw
009	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
010	Y312951		Not Available	ACCESS COVER, BACK

011	Y305086		Adjustable Leg And Nut
012	Y314137		Foot, Rubber
013	Y052740	62739	Nut, Lock
014	Y303361	Not Available	BASE ASSY. (UPPER & LOWER)
015	213007		Xfor Cabinet See Cabinet, Back
016	NLA	Not Available	CABINET (WHT)
017	NLA	Not Available	GROMMET, CORD

