


Maytag MDG10MNAGW 03 - CONTROL PANEL



Maytag [Residential Maytag MDG10MNAGW Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33001021			Panel, Control
2	215506			Screw, Control Panel Overlay
3	215003			Fastener, Panel And Bracket
4	33001280			Console
5	212276	W10116760		Screw
6	211252			Screw, Ground Wire
7	205810			Wire, Ground
8	314911		Not Available	BACK-UP PLATE - WHITE
9	306938			Knob, Selector Switch
10	307237	W10327105		Switch, Cycle Selection
11	Y313588	488234		Screw 8-32 X 1/4
12	308502		Not Available	HARNESS, WIRE
"	33001522			Harness, Wire
13	306940	W10149462		Switch, Push-To-Start
14	Y312706	422617		Nut
15	312751			Lockwasher, Start Switch

16	Y312702		Knurled Nut, Start Switch
17	22001365	W10139459	Lamp-Indicator 230 V.
18	215564		Lens, Indicator Light
19	Y305758		Timer 240-50
20	314723	W10133501	Cap, Knob
21	314725	33001500	Dial, Timer Indicator
"	33001500		Dial, Timer Indicator
22	Y313588	488234	Screw 8-32 X 1/4
23	312273		Nut, Control Knob
24	314724		Knob For Timer

