


# Maytag MDG11PDAAW 07 - MOTOR DRIVE



Maytag Residential Maytag MDG11PDAAW Dryer Parts Parts Diagram 07 - MOTOR DRIVE  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y312893</a>			Housing, Blower
002	Y303442			EXHAUST DUCT ASSEMBLY
003	410233	<a href="#">9703438</a>		Ring-Retrn
004	<a href="#">Y303836</a>			Blower Wheel Assembly And Clamp
005	<a href="#">312967</a>			Clamp, Blower Housing
006	Y312961	<a href="#">W10116751</a>		Screw
007	<a href="#">Y313561</a>			Screw---NA
008	<a href="#">307208</a>			Thermistor, Temp. Control
"	<a href="#">902577</a>			Capacitor, Thermostat
"	Y303391	<a href="#">33303391</a>		Thermostat, Cycling
009	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
010	<a href="#">306604</a>			Cut-Off, Thermal Part Not Used
011	NLA		Not Available	SCREW, THERMAL CUT-OFF
012	<a href="#">Y312901</a>			Seal, Housing Cover

013	314778		Not Available	COVER, BLOWER HOUSING
014	314818	<a href="#">1163839</a>		Screw
015	Y303358	<a href="#">W10410999</a>		Motor-Drve
016	<a href="#">Y015825</a>			Clip, Motor To Motor Support
017	910343	<a href="#">488234</a>		Screw 8-32 X 1/4
018	306207		Not Available	(PROD. No.303358-8 & No.303358-9)
"	NLA		Not Available	SWITCH, MOTOR EXTERNAL START
"	Y303877		Not Available	SWITCH, MOTOR EXTERNAL START No.303358-2, No.303358-4, 303358-7
"	<a href="#">Y303879</a>			Switch, Motor External Start
019	<a href="#">Y312959</a>			Poly "V" Belt For Tumbler
020	Y305185	<a href="#">6-3051850</a>		Pulley- MO
021	<a href="#">Y053241</a>			Set Screw, Motor Pulley
022	Y303945			IDLER SPRING ASSY. W/PLUG
023	Y303363	<a href="#">6-3033630</a>		Idler Arm
024	Y313582	<a href="#">W10116756</a>		Spacer
025	<a href="#">Y312527</a>			Washer, Idler Shaft
026	Y303705	<a href="#">6-3037050</a>		Pulley- ID
027	312958	<a href="#">354987</a>		Ring, Retaining
028	Y312894	<a href="#">315772</a>		Sleeve, Idler Arm
029	<a href="#">Y014874</a>			Screw, Idler Arm And Sleeve
030	<a href="#">901220</a>			Ground Wire
031	NLA		Not Available	SUPPORT, MOTOR
032	Y310632	<a href="#">1163839</a>		Screw
033	<a href="#">306261</a>			Base Assembly, Upper Dryer
"	306530		Not Available	BASE ASSEMBLY (LOWER)
034	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
035	<a href="#">210684</a>			Foot, Adjustable Leg
036	Y302699	<a href="#">22003428</a>		Leg, Adjustable
037	<a href="#">210385</a>			Lock Nut For Adjustable Leg
038	<a href="#">Y310376</a>			Clip, Door Switch Harness
039	315471	<a href="#">22003298</a>		Retainer, Wire
040	<a href="#">410490</a>			Spring, Retainer Wire Harness
041	Y312961	<a href="#">W10116751</a>		Screw
042	<a href="#">33001205</a>			Transformer
043	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">315218</a>			Shield, Transformer

*the laundry company*<sup>®</sup>