


Maytag MDG11PDAGL 02 - FRONT



Maytag [Residential Maytag MDG11PDAGL Dryer Parts](#) Parts Diagram 02 - FRONT

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	33001165			Top Cover Assembly
"	NLA		Not Available	(ALM)
002	NLA		Not Available	PLATE, COVER
003	NLA		Not Available	CABINET (UPR-WHT)
004	306261			Base Assembly, Upper Dryer
"	306530		Not Available	BASE ASSEMBLY (LOWER)
"	Y310632	1163839		Screw
005	910768	M0280301		Tie Electr
006	310933	33002194		Nut, Speed
"	314663	214354		Screw, Top Cover To Cabnt.
"	911050	4312464		Screw
"	NLA		Not Available	SUPPORT ASSEMBLY (WHT)
"	Y310632	1163839		Screw
007	NLA		Not Available	CABINET (LWR-WHT)
008	Y302699	22003428		Leg, Adjustable
009	210684			Foot, Adjustable Leg

010	210385		Lock Nut For Adjustable Leg
011	33001023	Not Available	EXTRUSION, CONTROL (LOWER)
012	314666	Not Available	SCREW, PANEL (UPR)
"	33001419	Not Available	PANEL, FRONT (UPR-WHT)
"	NLA	Not Available	PANEL, FRONT (UPR-ALM)
"	NLA	Not Available	CLIP, CABINET SCREW
013	211168	W10139210	Screw, 8-18 X 5/16
014	33001203	Not Available	PANEL, CLEAR INNER (W/SEAL)
015	314939		Handle, Door
"	314974		Handle, Door
016	314967	Not Available	DOOR W/WINDOW OUTER HALF (WHT)
"	NLA	Not Available	(ALM)
017	NLA	Not Available	NAME PLATE
018	Y313559		Screw
019	213007		Xfor Cabinet See Cabinet, Back
020	204439		Screw And Fstner Assembly
021	NLA	Not Available	EXTRUSION (UPR)
022	215506		Screw, Control Panel Overlay
"	315489		Screw, Extrusion And Front
023	33001132	33002342	Plug, Sifht Hole
"	33001168	Not Available	PLUG, SIGHT HOLE (ALM)
"	NLA	Not Available	PANEL, FRONT (LWR-ALM)
024	215506		Screw, Control Panel Overlay
025	Y313561		Screw---NA
"	314627		Bracket, Relays
"	Y310632	1163839	Screw
026	206421		Relay, Motor Reversing
"	212949	22001866	Screw, Relay
027	306398		Relay, Heater
"	Y251119	3177991	Screw

