


# Maytag MDG120P1HW 04 - MAIN DOOR SWITCH ASSEMBLY



Maytag [Residential Maytag MDG120P1HW Dryer Parts](#) Parts Diagram 04 - MAIN DOOR SWITCH ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICNA DRYER CORP AT 508-678-9000.
001	A102405	<a href="#">102405</a>		Lg. Dryer
"	A821097	<a href="#">821097</a>		Slotted Ma
"	A821098		Not Available	SWITCH, ASSEMBLY DOOR (COMPL.) (INCLUDES 1 - 4 & 6)
002	<a href="#">A150307</a>			Screw, Crimptite
003	A102405	<a href="#">102405</a>		Lg. Dryer
004	A137005	<a href="#">W10146741</a>		SDS Door S
005	A121028	<a href="#">121028</a>		1 4 X.032
006	A180155		Not Available	BLOCK, DOOR HINGE (ONLY) (35` CROSS GRAY)
007	A122705	<a href="#">122705</a>		Umnl Sok 2
008	A122626	<a href="#">122626</a>		15P Umnl C