


Maytag MDG120P1HW 16 - SAIL SWITCH ASSEMBLY



Maytag Residential Maytag MDG120P1HW Dryer Parts Parts Diagram 16 - SAIL SWITCH ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A105500	W10146641		Std Sail S
002	A319202	W10146866		Sail Switch
003	A154002	154002		1 8 Push O
004	A802800	802800		Sail Switch
"	A802801	802801		Sail Switch
005	A150300	5307527001		Switch
006	A150303	150303		4 X 3 4 P
007	A122200	122200		Sail Switch
008	A802799	802799		Sail Sw.bo
009	A150309	W10146761		10-16 X 1
010	A154004	154004		Tinneman