


# Maytag MDG12CSAAL 08 - CONTROL PANEL



Maytag [Residential Maytag MDG12CSAAL Dryer Parts](#) Parts Diagram 08 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33001707			PANEL, CONTROL
002	<a href="#">215506</a>			Screw, Control Panel Overlay
003	<a href="#">215003</a>			Fastener, Panel And Bracket
004	NLA		Not Available	CONSOLE (WHT)
005	212276	<a href="#">W10116760</a>		Screw
006	<a href="#">211252</a>			Screw, Ground Wire
007	<a href="#">205810</a>			Wire, Ground
008	314912		Not Available	BRACKET, CONTROL PANEL (WHT)
"	NLA		Not Available	(ALM)
009	<a href="#">306938</a>			Knob, Selector Switch
010	307237	<a href="#">W10327105</a>		Switch, Cycle Selection
011	Y313588	<a href="#">488234</a>		Screw 8-32 X 1/4
012	<a href="#">33001530</a>			Wire Harness, Main
013	306940	<a href="#">W10149462</a>		Switch, Push-To-Start
014	Y312706	<a href="#">422617</a>		Nut
015	<a href="#">312751</a>			Lockwasher, Start Switch

016 [Y312702](#)

Knurled Nut, Start Switch

017 204075

Not Available

PILOT LAMP (DG MODELS ONLY)

018 [215564](#)

Lens, Indicator Light

