


# Maytag MDG12CSAAW 09 - CONTROL CENTER



\* CONTACT YOUR COMMERCIAL LAUNDRY DISTRIBUTOR

Maytag [Residential Maytag MDG12CSAAW Dryer Parts](#) Parts Diagram 09 - CONTROL CENTER  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22001871		Not Available	VAULT, COIN (WHT)
"	22001872	<a href="#">22002885</a>		Vault, Coin
002	22001810		Not Available	STRAP, MOUNTING
003	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
004	<a href="#">910309</a>			Washer, Mounting Strap
005	<a href="#">22001870</a>			Gasket, Coin Vault
"	<a href="#">22001874</a>			Gasket, Coin Vault
006	Y052740	<a href="#">62739</a>		Nut, Lock
007	22001903	<a href="#">8576635</a>		Bolt
008	<a href="#">910387</a>			Lockwasher, Vault Assembly
009	<a href="#">Y052721</a>			Nut, Terminal Block Plate
010	NLA		Not Available	CAM, LOCKING
011	<a href="#">33001195</a>			Wire Harness, Timer
012	33001155	<a href="#">33002115</a>		Timer
013	<a href="#">22001881</a>			Grommet, Double
"	<a href="#">22001882</a>			Latch, Access Door

"	22001883	<a href="#">214354</a>	Screw, Top Cover To Cabnt.
"	22001910	<a href="#">22003679</a>	Timer Access Door Assembly
"	22001911	<a href="#">22003692</a>	Timer Access Door Assembly
014	33001688	<a href="#">33002598</a>	Actuator, Dryer Kit
015	<a href="#">33001275</a>		Torsion Timer Assembly
016	314337	<a href="#">33002968</a>	Slider
017	305798	Not Available	BYPASS SWITCH FOR MOTOR
018	<a href="#">Y305799</a>		Bypass Switch For Heater
019	<a href="#">211790</a>		Lock Ring For Timer Shaft
020	<a href="#">Y312270</a>		Clip, Spring Retainer
021	314330	Not Available	DRIVER FOR INDEX WHEEL (NOT INCLUDED W/KIT)
022	<a href="#">314335</a>		Peg, Tine Adjustment
"	314547	<a href="#">Y308109</a>	Slide And Adj. Return Bracket
023	<a href="#">314339</a>		Switch And Slider Bracket
024	<a href="#">314546</a>		Wheel, Index
025	<a href="#">211065</a>		Spring, Index Wheel
026	314548	<a href="#">33002967</a>	Actuator, Switch
027	<a href="#">33001708</a>		Bracket, Coin Slide
028	33001207	<a href="#">33002702</a>	Timer Bracket
029	NLA	Not Available	SPRING, HELICAL
030	<a href="#">314331</a>		Spring, Torsion Return
031	<a href="#">314332</a>		Spring, Actuator
032	<a href="#">306104</a>		Actuator Switch Kit
033	212707	<a href="#">3196385</a>	Screw
034	<a href="#">315277</a>		Screw
035	Y052634	<a href="#">701719</a>	Nut, Hex
036	910708	<a href="#">488234</a>	Screw 8-32 X 1/4
037	<a href="#">Y308991</a>		Motor, Timer
038	211168	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
039	NLA	Not Available	BRACE, COIN SLIDE

