


# Maytag MDG12CSABW 03 - CABINET-REAR



Maytag Residential Maytag MDG12CSABW Dryer Parts Parts Diagram 03 - CABINET-REAR  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y312905		Not Available	COVER, TERMINAL
002	33001284		Not Available	CORD, POWER
003	<a href="#">211881</a>			Grommet, Cord Part Not Used-Gas Models Only
004	NLA		Not Available	SCREW & WASHER ASSEMBLY
005	216423	<a href="#">3370225</a>		Screw
006	Y312951		Not Available	ACCESS COVER, BACK
007	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
"	<a href="#">Y305086</a>			Adjustable Leg And Nut
008	<a href="#">Y314137</a>			Foot, Rubber
009	Y052740	<a href="#">62739</a>		Nut, Lock
010	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
011	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
012	NLA		Not Available	CABINET (WHT)

013	<a href="#">Y313561</a>		Screw---NA
"	Y310632	<a href="#">1163839</a>	Screw
014	<a href="#">Y310376</a>		Clip, Door Switch Harness
015	<a href="#">Y313561</a>		Screw---NA

